

# PRODUCTOS

CODIGO	DESCRIPCION	PRECIO
BR-BM3850	MAQUINA COSER BROTHER 37 PUNTAS BR-BM3850	245
M1605	MAQUINA COSER SINGER 6 PUNTADAS M1605	291
M2405	MAQUINA COSER SINGER 8 PUNTADAS M2405	303
M3205	MAQUINA COSER SINGER 23 PUNTADAS M3205	330
MCO-7141(K)	MAQUINA COSER PREMIER MCO-7141(K)	221
MCO-7141(L)	MAQUINA COSER PREMIER MCO-7141(L)	221
MCO-7582	MAQUINA COSER PREMIER MCO-7582 20 PUNTADAS	140
S-3221	MAQUINA COSER SINGER SIMPLE 21 PUNTADAS S-3221	230
SI1306	MAQUINA COSER SINGER 6 PUNTAS SI1306	220
SI2263	MAQUINA COSER SINGER 23 PUNTAS SI2263	278
SI3223	MAQUINA COSER SINGER 23 PUNTAS SI3223	271
SI3229	MAQUINA COSER SINGER 29PUNTAS SI3229	281
SINGER-1412	MAQUINA DE COSER SINGER 12 PUNTAS SINGER-1412	145
SINGER-3337	MAQUINA DE COSER SINGER 37 PUNTAS SINGER-3337	260